Controlling other TVs with the remote commander

The remote commander is preprogrammed to control non-Sony TVs. If your TV is listed in the table below, set the appropriate manufacturer's code number.

1 Set TV/VIDEO at the top of the remote commander to TV.

2 Hold down I/⏻, and enter your TV's code number(s) using the programme number buttons.Then release I/⏻.

Now you can use the following TV control buttons to control your TV:

I/⏻, TV/VIDEO, programme number buttons, –/– – (ten's digit), PROG +/–, ◿ +/–, ▢ (TV), ▤ (Teletext), FASTEXT buttons, WIDE*, MENU*, CURSOR ↑*/↓*/←*/→*, and OK*.

* These buttons may not work with all TVs.

Tip

- When you set your TV's code number correctly while the TV is turned on, the TV turns off automatically.

Code numbers of controllable TVs

If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.

To switch to wide mode, see the footnotes below this table for the applicable code numbers.

Manufacturer	Code number
Sony	01*1, 02, 03, 04, 05
Aiwa	32
Akai	68
Blaupunkt	10, 21
Brionvega	40
C.G.M	09
Colonad	03
Dual	44
Emerson	03, 04
Fenner	30, 31
Ferguson	52
Goldstar	03, 04, 17
Grundig	10*1, 11*1
Hitachi	24
Hyper	31
Inno-Hit	41
Irradio	20
ITT	15, 16, 69*3
JVC	33
Loewe	45
Mitsubishi	27*1, 28*1, 50*1, 51*1
Mivar	09
NEC	66

Manufacturer	Code number
Nokia	15, 16, 69*3
Nordmende	35, 42
Orion	47, 48
Panasonic	17*1, 49
Philips	06*1, 07*1, 08*1
Phonola	18, 19
Pioneer	26
Saba	12, 13
Samsung	22, 23
Sanyo	25
Schneider	46
Seleco	14
Sharp	29
Siemens	39
Sinudyne	37
TEAC	67
Telefunken	36
Thomson	43*2
Toshiba	38
White Westinghouse	34

*1 Press WIDE to switch to the wide picture mode you want.

*2 Press WIDE, then press ◿ +/– to select the wide picture mode you want.

*3 Press WIDE. The menu appears on the TV screen.Then, press CURSOR ↑/↓/←/→ to select the wide picture you want and press OK.

continued